


How to set cross-line turn

Introduction

With cross-line turn, it is easy to make a U turn with smaller implements.


Steps

1. Go to Settings - Guidelines to select an AB line, then click the U turn function as below,







2. Select Model1 and select cross-line number as 1(currently just 1 is supported)



3. Return to main interface and switch to automatic mode, then click the turn icon the tractor will automatically perform a cross-line turn.







CHC Navigation

Building C, 577 Songying Road, Qingpu, District,
201702 Shanghai, China

Tel: +86 21 542 60 273 | Fax: +86 21 649 50 963

Email: sales@chcnav.com | support@chcnav.com

Skype: chc_support

Website: www.chcnav.com

Shanghai Huace Navigation Technology Ltd.
Building C, 577 Songying Road, Qingpu, District,
201702 Shanghai, China

WWW.CHCNAVCOM
Tel: +86 21 54260273
Stock Code:300627